

PIGSKIN



OPERATIONS MANUAL

including:

*Game Operation & Adjustment
Game Testing & Problem Diagnosis
Parts Information
Reference Diagrams & Schematics*

MIDWAY MANUFACTURING COMPANY
3401 N. California Avenue
Chicago, IL 60618

PIGSKIN
SIX-TWENTY-ONE A.D.
(Ancient Arch Rivals on a Rampage!)

The rigors of day to day existence in the early part of the Seventh Century A.D. were far more severe than those most of us face today. It is no surprise then, that the era produced "Role Models" of a slightly different sort.

Men like: Attila DeSoiled; whose infamous "Mongrel Horde" spent much of their free time sweeping across Central Asia into the dustbins of Eastern Europe.

Men like: Thor Akenbak; the renegade Viking whose piercing battle cry "... Loot and pillage, loot and pillage, Let's go find us an English Village..."

In the Dark Ages, the world's wildest warriors had a word for "mind blowing, bone crunching, heart-stopping" excitement.....PIGSKIN!

PIGSKIN 621 A.D. is a thoroughly researched, unflaggingly faithful re-creation of those exciting, fictitious days of yore when "Good, Clean Fun" was simply known as "Fun".

Each player directly controls one of a half-dozen hulking barbarians in a bone-crushing "battle for the ball" across a medieval countryside.

The object of the game: to inflict as much pain and suffering as possible on the opposition and carry the PIGSKIN back to your "stronghold" (your ship or castle) more times than your opponent can and thereby win the battle!

TABLE OF CONTENTS

SECTION 1 OPERATION & TROUBLESHOOTING

| | |
|--|------|
| Safety | 1-2 |
| Set-up Procedure | |
| Installation & Inspection..... | 1-3 |
| Location Requirements..... | 1-3 |
| Cabinet Assembly Diagram..... | 1-4 |
| Servicing | 1-5 |
| Game Features | |
| Starting-up..... | 1-7 |
| Player Controls..... | 1-7 |
| Control Panel Diagram..... | 1-7 |
| Game Operation | 1-8 |
| Control Switches..... | 1-8 |
| Control Switch Location Diagram..... | 1-8 |
| Game Adjustment & Diagnostics | |
| Starting-up..... | 1-9 |
| Main Test Menu..... | 1-9 |
| Diagnostic Tests..... | 1-10 |
| Switch Test..... | 1-10 |
| DIP Switch Test & Chart..... | 1-11 |
| Troubleshooting | 1-12 |

SECTION 2 PARTS INFORMATION

| | |
|---------------------------------|------|
| PIGSKIN PARTS | 2-2 |
| Audio Board..... | 2-6 |
| 49 Way Joystick Drawing..... | 2-7 |
| 49 Way Joystick Opto Board..... | 2-8 |
| PIGSKIN CPU Board..... | 2-9 |
| Power Supply..... | 2-11 |
| Lamp Driver Board..... | 2-12 |

SECTION 3 DIAGRAMS & SCHEMATICS

| | |
|-------------------------------------|------|
| Audio Board Schematic..... | 3-2 |
| Lamp Driver PC Board Schematic..... | 3-3 |
| 49 Way Joystick Schematic..... | 3-4 |
| PIGSKIN PCB Schematic..... | 3-5 |
| JAMMA Edge Connector Chart..... | 3-17 |
| Cabinet Wiring Diagram..... | 3-18 |
| Control Panel Wiring Diagram..... | 3-19 |
| Lamp Driver Board Diagram..... | 3-20 |
| Power Wiring Diagram..... | 3-21 |
| Interboard Wiring Diagram..... | 3-22 |

PIGSKIN RULES

Each player directly controls an armoured "team captain" ; and indirectly controls up to 5 teammates. Each player has the following to control the character selected:

- 1 49 Way Joystick
- 2 Punch Button(s) (whichever is more comfortable)
- 1 Pass Button
- 1 Team Attitude Adjustment Button

Punch buttons allow a player to throw punches (all teammates throw punches when pressed). It can also be used along with the pass button while on defense (press both buttons to attempt a flying tackle).

The Pass button allows the player to pass or kick the ball to a teammate (passplays are shown on the screen and the player has the choice of which one to select).

Team Attitude Adjustment Buttons are used to select a style of play (get the ball, man to man, bad attitude, etc.).

Players may pick up "concealed weapons" by simply running over them. Weapons are used automatically during "grapples" involving the Pigskin. Characters that are severely injured by weapons are revived after the next goal is scored.

A "grapple" is a savage battle for the pigskin, which is usually won by the team with the most players involved in it.

The terrain will affect a character's movement (Mud, rocks, swampy areas, etc.). Players that remember how a field is "mapped out" may learn to use the terrain to their advantage.

Players score points for carrying the Pigskin (1 point for every 5 seconds in the player's possession), and for scoring a goal (6 points).


IMPORTANT NOTICE

To Receive A Free Player's Handbook Including:

- Rules
- Designer's Notes
- Strategies
- Pigskin Product Information
- Game Tips

Send a Self Addressed Stamped Envelope to:

PIGSKIN
P.O. BOX 1000
PLANO, IL 60545



PIGSKIN

Game Operation & Troubleshooting Information

S
E
C
T
I
O
N
O
N
E

Safety Notices

The following safety hints apply to all game operators and service personnel. Specific warnings and cautions will be found throughout this manual where they apply. We recommend that you read this page, and also all of Section 1, before preparing your game for play.

WARNINGS

AC POWER CONNECTION. Before connecting the game to the AC power source, verify that the "line voltage selection chart" jumper wires are installed correctly for the line voltage in your area. For details, refer to Section 3.

PROPERLY GROUND THE GAME. To avoid electrical shocks, do not plug in the game until it has been inspected and properly grounded. Bally/Midway games should only be plugged into a grounded 3-wire outlet. Shocks will also result, if the control panel is not properly grounded! After servicing any parts on the panel, assure that the grounded wires are secure. Only then should you lock up the game.

DISCONNECT POWER DURING REPAIRS. To avoid electrical shock, disconnect the game from the AC power source before removing or repairing any part of the game. When removing or repairing the monitor, extra precautions must be taken to avoid electrical shock because high voltages may exist within the monitor circuitry and cathode ray tube (CRT) even after power has been disconnected. Do not touch internal parts of the display with your hands or metal objects! Always discharge the CRT: attach one end of a large, well-insulated, 20-kV jumper to ground. Momentarily touch the free end of the grounded jumper to the anode by sliding it under the anode cap. Wait two minutes and discharge the anode again.

USE THE PROPER FUSE. To avoid electrical shock, use the replacement fuse which is specified in the parts list for this game. The replacement fuse must match the original fuse replaced in fuse type, voltage rating, and current rating.

HANDLE FLUORESCENT TUBE AND CRT WITH CARE. If you drop a fluorescent tube or CRT and it breaks, it will implode! Shattered glass can fly eight feet or more from the implosion.

CAUTION

PROPERLY ATTACH ALL CONNECTORS. Make sure that the connectors on each printed circuit board (PCB) are properly connected. If they do not slip on easily, do not force them. A reversed connector may damage your game and void the warranty. All connectors are keyed to fit specific pins on each board.

Setup Procedure

Installation and Inspection

1. Remove the game from its shipping carton, and inspect the exterior of the cabinet for any signs of damage. Remove the shipping cleats from the bottom of the cabinet.
2. Remove keys from the taped coin return slot (or attached to joystick). Unlock and open the coin and cash box doors. (Leg levellers and spare parts are stored in the cash box.)
3. Locate the four threaded holes on the bottom of the cabinet (one in each corner), and install one leg leveller (with its hex nut) in each hole.
4. Stand the cabinet upright and make certain that it is in a stable position. Level the cabinet.
5. Unscrew (or unlock) and remove the rear doors/panels of the cabinet. Inspect the interior for any signs of damage. Check all major assemblies to assure that they are mounted securely.
6. Refer to the game's cabinet wiring diagram (Section 3), and check to see that all cable connectors are correctly secured and firmly seated. **DO NOT FORCE CONNECTORS.** Watch for damaged connectors and avoid making reversed connections.
7. **Line Voltage Selection.** Your game is designed to work properly on the line voltage where you are located. Determine the value of your line voltage with a meter. Then, check the power input wires to the main power supply transformer on your game to be sure they are connected to taps which correspond to your local line voltage value. If necessary, reconnect the power input wires to the transformer in accordance with the Transformer Chart in Section 3.

If the line voltage in your area falls outside the upper or lower limits of the range of voltage inputs covered by the main power supply transformer, **DO NOT PLUG YOUR GAME IN** until you have contacted your distributor or the Bally/Midway Service Department and obtained a solution to the problem. Otherwise, you could damage your game.

8. Lay the line cord (connected to the Power Chassis) in the slot along the bottom edge of the lower rear cabinet door/panel. Install the rear cabinet doors/panels and screw (lock) them securely. Close and lock the front coin and cash box doors.

9. Connect the line cord to a grounded (3-terminal) AC wall outlet.

10. Switch ON the game, using the ON/OFF switch located on the upper left rear of the cabinet, to verify proper operation.

GAME LOCATION REQUIREMENTS

Power

Domestic 115V @ 60 Hz
Foreign 230V @ 50 Hz


Temp.

32° F to 100° F
(0° C to 38° C)

Humidity

Not to exceed 95% relative.

CABINET ASSEMBLY DIAGRAM



Servicing

■ Servicing the Control Panel

Switch OFF power to the game. The control panel is held in place by four latches (located on the left and right sides of the cabinet) which provide constant pressure on the strikes. The latches can be reached through the coin door opening. To release the latches, lift the latch handle and unhook the wire fasteners. Carefully use the joysticks to lift the control panel. Rest the panel on its support bracket, while working on it. To reinstall the control panel, check for proper cable connections, including the ground strap, and use the joysticks to lower it into position, avoiding pinched wires. Reclamp the latches.

NOTE

To remove the control panel for bench servicing, release the latches and lift the control panel, until it rests on its support bracket. Disconnect the cables and the ground strap. Lift the control panel out of the game cabinet.

■ Removal of Viewing Glass

Switch off power to the game, and open the control panel. Unscrew the four nuts at the bottom of the glass and remove the protective black plastic strip. Carefully lift the glass from its bottom groove and lift it clear of the cabinet.

■ Removal of Monitor Bezel

Switch off power to the game, and remove the viewing glass. Remove the bezel securing screws to free the monitor bezel.

■ Monitor Replacement

We recommend that you read the WARNINGS section thoroughly before beginning this procedure.

Switch off power to the game. Open the upper rear door/panel. Remove the viewing glass and the monitor bezel. Completely disconnect the monitor from all of its cabling, including its chassis ground strap. Remove the four bolts securing the monitor's mounting flanges to its mounting panel. Pull the monitor carefully from the cabinet front.

CAUTION

The monitor DOES NOT contain an isolation transformer in its chassis (it is mounted instead in the Power Chassis Assembly located on the floor of the cabinet). When servicing the monitor on a test bench, YOU MUST ISOLATE THE MONITOR FROM THE LINE VOLTAGE WITH AN ISOLATION TRANSFORMER.

CAUTION

While removing the four bolts, firmly support the monitor from the front of the crt so that it will not slip.

WARNING

If you drop a fluorescent tube and it breaks, it will implode! Use care in handling.

■ **Removal of the Header Attract Glass**

Switch off the power to the game. The glass is held in place by retaining brackets at the top and bottom of the glass. The top retaining bracket is secured to the cabinet by five torx® tamper-resistant screws. Remove these screws using the proper torx® tool.

The fluorescent light tube starter may also be replaced at this time. Grasp the starter (located on the back of the mounting bracket of fluorescent light assembly), give it a quarter turn, and remove it from its socket. Carefully place a new tube starter into the socket, and turn to reinstall.

■ **Removal of the Fluorescent Light Assembly**

After switching off the power to the game, remove the header glass. Disconnect the fluorescent light assembly from its power cable. Remove the screws which secure the assembly to the cabinet and lift out the assembly.

■ **Removal of the Speakers**

Switch off the power to the game. Take out the tamper-resistant screws which secure the speaker grille to the cabinet, and remove the speaker grille. Remove the rear cabinet door. Disconnect both speakers from their cabling. Each of the two speakers is secured to the cabinet with two carriage bolts and two hex nuts. Remove the speakers by removing the nuts and sliding the bolts out of the cabinet. Note that, in the process, the ground wires to both speakers are also removed.

■ **Volume Control and Diagnostics Switches**

Looking inside the coin door, you will find the game's control switches. Located towards the near left corner is the Power Interlock Switch. The Volume Control Potentiometer is the white knob located on left side of the bracket which is mounted at the rear of the coin box. Turning the knob clockwise will increase volume. The upper right switch on the bracket is the Test/Diagnostics Switch which enables you to enter the game's test mode. Finally, the lower right switch located on the bracket is the Service Credit Switch, which enables you to add credits to a game for service testing without affecting the game's book-keeping total.

■ **Option Switch Settings**

The option switch controls all game options. It is located on the 68000 Video Board which is mounted inside the lower portion of the cabinet. Refer to the Video Board Reference Drawing for option switch settings.


Game Rules and Features

Starting Up

Switch on the power to the game. A "rug" pattern appears on the CRT screen. When the "rug" pattern ends, the screen shows CHECKING SCRATCH RAMS, and then CHECKING ROMS. The next screen shows PIGSKIN REVISION LEVEL, CMOS TEST OK and the Coin Setting. The game then moves to the attract mode. After the proper coinage has been inserted, the game exits the attract mode and enters playmode.

Player Controls

- Each Credit Button allows (1 or 2) players respectively, to begin play or continue play.
- Each Joystick enables players (1 or 2) respectively, to move their team captain.
- Four Buttons (per player) control Team Attitude Adjustment, Punch, and Pass. See Diagram below for locations.




Game Operation

PIGSKIN is a one or two player video game with a color monitor. From the player's perspective, the game has two modes of operation: Ready-to-Play and Play. For the owner/operator, the game has an additional mode of operation called Game Diagnostics and Adjustments.

Control Switches

- The **COIN DOOR SLAM TILT SWITCH** detects any forceful vibrations against the Coin Door. This eliminates pounding for free games.
- The **VOLUME CONTROL** allows increasing or decreasing the volume level of the game music and speech. For greater profits, set your game's volume level at its maximum.
- The **TEST/DIAGNOSTICS SWITCH** allows you to enter into the game's Diagnostic mode. Move the Test Switch to the left, then back to the right to enter the Diagnostics Mode. To exit this mode, select EXIT TO GAME OVER from the Diagnostics main menu.
- The **SERVICE CREDIT SWITCH** is a special feature switch that allots credit without affecting the game's bookkeeping total.
- The **POWER INTERLOCK SWITCH** is a safety switch that ensures power to the game is turned off during servicing. This switch is located inside the lower rear door/panel.



Game Adjustments & Diagnostics


Starting Up

All PIGSKIN game adjustments and diagnostics are menu-driven features. Each menu lists several choices that you may act upon as desired. PIGSKIN contains many menu levels (i.e., one menu selection will send the game to another menu).

Switch on the power to the game. Locate the Test Switch and push it towards the left to activate the PIGSKIN Diagnostics mode. The first menu you see is the main test menu. Game adjustments, book-keeping, and diagnostics are all available from this menu.

Once in the main test menu, use the PLAYER JOYSTICK to select an option and the one or two player CREDIT BUTTON to enter into it. Notice that the selected option is always the one that has the cursor in front of it.

The main test menu lists six diagnostic options to enter.



Main Test Menu

PIGSKIN DIAGNOSTICS & ADJUSTMENTS

SELF TEST

This test is designed to locate and identify any computer malfunctions. When selected, the game enters this mode immediately and begins scanning its memory. The phrases "PASSED TEST" or "FAILED TEST" will appear on the screen depending on whether the test was successful or not.

SWITCHES

The Switch and Sound Self-Test mode allow the operator to determine if all game switches, sound features, and the opto-board controlled joysticks are operating properly. The operator can activate switches one at a time and check the monitor screen to see if they are acknowledged.

GRID

The Convergence Grid Display Test displays a crosshatch pattern to aid in adjusting the color monitor. This pattern is useful in adjusting the color balance, convergence, vertical linearity, and vertical/horizontal sizing. To exit this test, press the Tilt switch.

DIP SWITCH

Game options are adjustable by changing the bit switch settings on the DIP Switch Table (shown on the next page). The DIP Switch unit combines seven bit switches, which are set to the ON or OFF position. When you enter this test mode, the screen shows a full display of current DIP Switch settings.

RESET HISCORE

The operator may reset the high scores by pressing both the 1 and 2 Player Credit Buttons simultaneously.

LIGHT TEST

The Light Test allows the operator to determine if all the "Player Awareness" Lights are working correctly. Simply press the Player 1 Credit Button to run through the lights.

PIGSKIN DIP SWITCH TABLE

| | | | | |
|------|---|-----|---|-------------------------------|
| BITS | 1 | OFF | → | MEDIUM |
| | 2 | OFF | → | PRESET TIME |
| | 1 | ON | → | SHORT |
| | 2 | OFF | → | TIME |
| | 1 | OFF | → | LONG |
| | 2 | ON | → | TIME |
| | 1 | OFF | → | SHORTEST |
| | 2 | ON | → | TIME |
| BITS | 3 | OFF | → | 1 COIN 1CREDIT |
| | 4 | OFF | → | |
| | 3 | ON | → | 2 COIN GAME |
| | 4 | OFF | → | |
| | 3 | OFF | → | SET YOUR OWN COIN * |
| | 4 | ON | → | OPTIONS |
| | 3 | ON | → | FREE PLAY |
| | 4 | ON | → | |
| BIT | 6 | OFF | → | BLANK |
| BIT | 6 | ON | → | TEST SWITCH ON |
| BIT | 7 | OFF | → | BLANK |
| BIT | 7 | ON | → | INDEPENDENT COIN *, CHUTES |

* After selecting this option through DIP SWITCH (3 & 4) return to the main menu and select (Coin Settings). Select the desired number of coins with the player 1 (increments of 1) & player 2 credit buttons (decrements of 1). Follow the same procedure for selecting the desired number of credits per coin.

NOTE: This menu item will only be displayed when the appropriate Dip Switches have been correctly set as shown in the table above.

** After selecting this option through DIP SWITCH (7) return to the main menu and select (Independent Coin Chutes). Select a coin chute by pressing the one or two player credit button. Set the Coin and Credit options in the same manner as explained above.

NOTE: This menu item will only be displayed when the appropriate Dip Switch has been correctly set as shown in the table above.

Troubleshooting

| Problem | Possible Solution |
|---|--|
| NO PICTURE OR DISTORTED PICTURE. | Check for faulty video board or monitor. Check for disconnected video signal cable. |
| TURN GAME ON & NOTHING HAPPENS | Check line fuse. Check for +5V dc at pins C, D, 3, and 4 of the JAMMA Connector.(Check for LED on CPU Board.) |
| NO SOUND | Check the speaker and speaker connection to pins L and 10 on JAMMA Connector. Check volume control setting. Check for +12V dc at pins F and 6 on the JAMMA Connector. Check Interboard wiring from CPU Board to Sound Board. |
| NO GENERAL ILLUMINATION | Check the 1A., S-B fuse on the Lamp Driver Board. |
| MOVE JOYSTICK, BUT PLAYER DOES NOT MOVE OR FIRE | Check for open wires between Joystick and CPU Board. Check for contamination on Joystick switch contacts and CPU Board pins. Check for proper ground. |
| PRESS START BUTTON AND NOTHING HAPPENS | Check for open wires between button and CPU Board. Check for contamination on CPU Board pins or button switch blade contacts. Check for proper ground. |
| NO CREDIT GIVEN WHEN COINS ARE INSERTED | Check DIP switch coin setting. Check for contamination on coin switch contacts. Check for an open wire between Coin Switch 1 and pin 16 on JAMMA Connector or Coin Switch 2 and pin T of JAMMA Connector. |
| TOO MANY CREDITS FOR NUMBER OF COINS INSERTED | Check Game Pricing setting. Check for a short between pins T & 16 on JAMMA Connector. |
| GAME STAYS IN THE TEST MODE. | Check that the Test Switch in the coin door and the Test Switch (Position 8) on DIP Switch 2 are set to Off. |

PIGSKIN

Game Parts Information

S
E
C
T
I
O
N

T
W
O

Description**Part Number****Battery**

Lithium Battery, 3V

5880-11056-00

Cables

| | | | |
|--------------------------|-----------|---------------------------|----------|
| Coin Door Cable | H-13842 | Sound Board Jumper Cable | H-12758 |
| Power Pak Jumper Cable | H-13265 | Speaker Cable | H-13213 |
| Video Switch Power Cable | H-10217-4 | Control Panel Cable | H-13790 |
| Video Signal Cable | H-12746-2 | Main Harness Cable | H-13791 |
| Line Voltage Cable | H-13789 | Sound/Speaker Cable | H-13827 |
| Line Filter Jumper Cable | H-13344 | Lamp Board Cable Assembly | H-13828 |
| Transformer Jumper Cable | H-13378 | Volume Control Cable | H-8865-5 |

Electrolytic Capacitors

| | |
|----------------------------------|---------------|
| 10 μ F at 20V \pm 20% | 5040-09343-00 |
| 1 μ F at 63V \pm 50-10% | 5040-09365-00 |
| 470 μ F at 16V \pm 50-10% | 5040-09776-00 |
| 100 μ F at 35V | 5040-10974-00 |
| 1000 μ F at 16V \pm 20% | 5040-12006-00 |
| 10 μ F at 10V \pm 10% | 5041-09243-00 |
| 0.01 μ F at 50V \pm 80-20% | 5043-08980-00 |
| 0.1 μ F at 50V \pm 20% | 5043-08996-00 |
| 470pF at 50V \pm 20% | 5043-09065-00 |
| 100pF at 50V \pm 20% | 5043-09492-00 |
| 47pF at 50V \pm 20% | 5043-09844-00 |
| 1000pF at 50V \pm 20% | 5043-09845-00 |
| 1200pF at 50V \pm 5% | 5046-09346-00 |
| 180pF at 100V \pm 5% | 5046-09350-00 |
| 0.0047 μ F at 50V \pm 10% | 5048-10992-00 |
| 100pF at 50V \pm 5% | 5048-11029-00 |
| 390pF at 50V \pm 10% | 5048-11064-00 |
| 820pF 10% AXIL | 5048-12506-00 |
| .47 at 50V AX | 5048-12577-00 |

Fluorescent Lamp Parts

| | |
|--|---------|
| Fluorescent Light Fixture -60H | 20-9590 |
| Fluorescent Light Bulb, #555, 6.3V. .25A. | 24-8768 |
| Fluorescent Light Bulb, 15W, 18" | 24-8809 |


| | Description | Part Number | |
|-------------------------------|--------------------------|--------------------------|--------------|
| Transformers | | | |
| | Transformer | 5610-12291-00 | |
| Line Filter | | | |
| | 5 Amp Line Filter | 5102-08895-00 | |
| Pots & Switches | | | |
| | DPAT, 227V, 15 Amps | 5640-10932-00 | |
| | SPST, Switch | 5640-12540-00 | |
| | Pushbutton SPS | 5641-12539-00 | |
| | Pushbutton PC Mount | 5641-12551-00 | |
| | Interlock Cheater Switch | 5643-09556-00 | |
| | 10 Position DIP Switch | 5645-12512-00 | |
| | Universal Switch, Molded | 03-7614 | |
| | Bracket Interlock Switch | 01-9399 | |
| | Bracket-Test Switch | 01-9383 | |
| Single Inline Packages | | | |
| | 4.7K, 9R 10P, 5% | 5019-09362-00 | |
| | 4.7K & 470pF x 8 | 5060-10396-00 | |
| | 1K & 9R 10% | 5019-09669-00 | |
| | 100K & 9R, 10P, 5% | 5019-12509-00 | |
| Speakers | | | |
| | 6", 8Ω Speaker, 20W | 5555-12015-00 | |
| | 4" Piezo Speaker, 50W | 5555-12068-00 | |
| Control Panel | | | |
| Control Shelf Assembly | D-13551 | Universal Switch Molding | 03-7614 |
| Control Shelf Plate | 01-9618 | Wood Control Shelf | 11-939 |
| Red Button Assembly | C-9214-4 | 5/8 Palnut | 20-9222 |
| White Button Assembly | C-9214-5 | Screened Overlay | 31-1549-4004 |
| Yellow Button Assembly | C-9214-6 | 49W Joystick Assembly | C-9477-1 |
| Latch Bracket | 01-6994 | | |
| Latch Bracket | 01-9605 | | |

Description

Part Number

| | Description | Part Number |
|---------------------------------------|---------------------------|---------------|
| Analog ICs | 2002 Audio Amplifier | 5370-09156-00 |
| | 1458 Op Amp | 5370-09321-00 |
| Oscillators | 8 MHz Oscillator | 5521-10931-00 |
| | 16 MHz Oscillator Clock | 5521-12501-00 |
| | 20 MHz Oscillator Clock | 5521-10743-00 |
| RAM ICs | 5516-2 CMOS RAM 2K x 8 | 5340-10139-00 |
| | 93419 SRAM | 5340-12496-00 |
| | 2018 SRAM | 5340-12497-00 |
| | 6116 SRAM | 5340-12500-00 |
| | Low Power 8K x 8 SRAM | 5340-12558-00 |
| Random Logic | 74LS139 2/4 Decoder | 5281-09246-00 |
| | 74LS138 Demultiplexer | 5281-09745-00 |
| | 74LS74 Dual D Flip-Flop | 5281-09487-00 |
| | 74LS04 Hex Inverter | 5281-09215-00 |
| | 74LS10 Triple NAND | 5281-09235-00 |
| | 74LS175 | 5281-10043-00 |
| Transistors | 2N4123 NPN | 5160-12510-00 |
| | 2N3904 NPN | 5160-10269-00 |
| Diodes & Varistors | 130V, 10 Joules Varistor | 5017-09044-00 |
| VLSI Chips | 68B09E Microprocessor | 5400-10320-00 |
| | 68B21 PIA | 5430-10322-00 |
| | YM2151 Yamaha Synthesizer | 5370-11086-00 |
| Miscellaneous Electronic Parts | 1408 D/A Converter | 5371-09152-00 |
| | YM3012 D/A Converter | 5371-11087-00 |
| | 3.58 MHz Crystal | 5520-09020-00 |
| | 55536 CVSD | 5370-09691-00 |
| Monitor | Monitor 19" | 5675-12560-00 |
| Manuals | Monitor Manual | 16-3000-103 |
| | Instruction Manual | 16-4004-101 |

| | Description | Part Number |
|--|--------------------------------|----------------|
| Metal & Wooden Parts | | |
| | Cabinet | 11-936 |
| | Coin Door-USA | 09-20000-V-1 |
| | Back Door | 11-948-1 |
| | PCB Board Shelf | 11-936-2 |
| | Speaker Panel | 11-936-3 |
| | Wood Control Shelf | 11-939 |
| | Wire Key Hook | 12-6230 |
| Rubber, Glass & Plastic Parts | | |
| | Screened Marquee | 31-1542-4004-U |
| | Decal, Player One/Two, Offense | 31-1548-4004-1 |
| | Decal, Player One/Two, Defense | 31-1548-4004-2 |
| | Screened Overlay | 31-1549-4004 |
| | Screened Football | 31-1556-4004 |
| | Screened Backdrop | 31-1563-4004 |
| Major Assemblies | | |
| | Cabinet Assembly | A-13768-4004 |
| | Back Door Assembly | B-12590-1 |
| | Caster Wheel Assembly | B-13086 |
| | Test Switch Assembly | A-13115 |
| | Speaker Grille Assembly | B-13600 |
| | Switcher Power Supply Assembly | C-13253 |
| | Line Voltage Cable Assembly | C-12773-7 |
| | Mounting Plate Toggle Assembly | A-9958 |
| | PC Board Shelf Assembly | C-13532 |
| | Speaker Shelf Assembly | C-13533 |
| | Power Pak Chassi Assembly | D-12356 |
| | Line Cord Assembly - USA | A-13340 |
| | Control Shelf Assembly | D-13551 |
| | 49 Way Joystick Assembly | C-9477-1 |
| | PCB Lamp Assembly | C-13797 |
| | PCB Lamp Driver Assembly | C-13765 |
| | Opto-Board (49JS) Assembly | C-9471 |
| PC BOARDS | | |
| | PIGSKIN CPU Board | C-13246-4004 |
| | Sound Board Assembly | D-11581-4004 |



Audio Board Assembly


p/n D-11581-4004

| Part Number | Ckt Designator | Description | Part Number | Ckt Designator | Description |
|------------------|---|------------------------------|---------------|--------------------------|------------------------------------|
| 5700-10176-00 | U4, U19, U20 | Socket, IC, 28 PIN | 5010-10985-00 | R14, R15 | Resistor, 20K, 1/4w, 5% |
| 5766-12130-00 | | Bare P. C. Board | 5010-09034-00 | R22-R24, R17, R34 | Resistor, 10K, 1/4w, 5% |
| 5371-11087-00 | U1 | IC, D/A Conv, YM3012 | 5010-09324-00 | R6, R19, R20, R21 | Resistor, 27K, 1/4w, 5% |
| a) 5700-09006-00 | | Socket, IC, 16-pin (U1) | 5010-09086-00 | RIG | Resistor, 8.8K, 1/4w, 5% |
| 5370-11086-00 | U3 | IC, Sound Processor, YM2151 | 5010-09534-00 | | Resistor, 0Ω, C.F., 1/4W |
| a) 5700-09004-00 | | Socket, IC, 24-pin (U3) | 5010-09162-00 | R39 | Resistor, 100K, 1/4w, 5% |
| 5400-10320-00 | U8 | IC, μProcessor, MC68B09E | 5010-09331-00 | R16 | Resistor, 13K, 1/4W, 5% |
| a) 5700-08985-00 | | Socket, IC, 40-pin (U8) | 5010-08772-00 | R18 | Resistor, 15KΩ, 1/4W, 5% |
| 5343-4004-1 | U4 | IC, Audio ROM 1 | 5010-08824-00 | R32 | Resistor, 43KΩ, 1/4W, 5% |
| 5343-4004-2 | U19 | IC, Audio ROM 2 | 5010-08846-00 | R31 | Resistor, 220KΩ, 1/4W, 5% |
| 5343-4004-3 | U20 | IC, Audio ROM 3 | 5010-08991-00 | R12 | Resistor, 4.7KΩ, 1/4W, 5% |
| a) 5700-10176-00 | | Socket, IC, 28-pin (U4, U19) | 5010-09219-00 | R38 | Resistor, 8.2K, 1/4W, 5% |
| 5371-09152-00 | U11 | IC, D/A Convtr, MC1408 | 5010-10258-00 | R40 | Resistor, 1M, 1/4w, 5% |
| 5430-10322-00 | U12 | IC, PIA, MC68B21 | 5010-09179-00 | R10 | Resistor, 3.3M, 1/4w, 5% |
| 5340-10139-00 | U5 | IC, RAM/S 5516-2 2Kx8 | 5010-09333-00 | R29 | Resistor, 180KΩ, 1/4W, 5% |
| 5281-09487-00 | U16 | IC, Dual D Flipflop, 74LS74 | 5010-09342-00 | R30 | Resistor, 36KΩ, 1/4W, 5% |
| 5281-10043-00 | U13 | IC, 74LS175 | 5010-09534-00 | W9 | Resistor, 0Ω, 1/4w, 5% |
| 5281-09235-00 | U21 | IC, Triple NAND, 74LS10 | 5040-09343-00 | C1, C3, C4, C8, C17 | Capacitor, 10μfd, 20v, ±20% |
| 5370-09321-00 | U9, U10, U17, U18 | IC, Op Amp, MC1458 | 5040-10974-00 | C12, C19, C24 | Capacitor, 100μfd, 35v |
| 5281-09215-00 | U2 | IC, Hex Inv, 74LS04 | 5040-09776-00 | C26, C30 | Capacitor, 470μfd, 16v; +50, -10% |
| 5281-09246-00 | U14 | IC, 2-4 Dec, 74LS139 | 5040-12006-00 | C29, C32 | Capacitor, 1000μfd, 16v, 20% |
| 5281-09745-00 | U15 | IC, Dual Mux, 74LS138 | 5041-09243-00 | C25, C28 | Capacitor, 10μfd, 10v, ±10% |
| 5370-09156-00 | U22, U23 | IC, Audio Amp, TDA2002 | 5043-08980-00 | C5, B (20)* | Capacitor, 0.01μfd, 50v, +80, -20% |
| a) 5705-09199-00 | | Heatsink, #8030B | 5043-08996-00 | C31, C33 | Capacitor, 0.1μfd, 50v, ±20% |
| b) 4006-01003-06 | | Mach. Screw, 6-32 x 3/8 | 5043-09085-00 | C13 - C15 | Capacitor, 470 pfd, 50v, ±20% |
| c) 4406-01117-00 | | Nut, 6-32 Hex. | 5043-09492-00 | C2, C34 | Capacitor, 100 pfd, 50v, ±10% |
| d) 4703-00007-00 | | Lockwasher, #8 Ext. | 5043-09844-00 | C6 | Capacitor, 47 pfd, 50v, ±20% |
| 5160-10269-00 | Q1 | Transistor, 2N3904, NPN | 5043-09845-00 | C16, C18, C20 - C23, C27 | Capacitor, 1000 pfd, 50v, ±20% |
| 5060-10396-00 | SP1 | SIP 4.7K & 470pfd, 8R8C | 5040-09365-00 | C11 | Capacitor, 1μfd, +50v, -10% |
| 5010-09181-00 | R44, R48 | Resistor, 1.0Ω, 1/2w, 5% | 5046-09346-00 | C7 | Capacitor, 1200P, 50v, +/-5% |
| 5010-09161-00 | R35, R45 | Resistor, 2.2Ω, 1/4w, 5% | 5048-10992-00 | C10 | Capacitor, 4700P, 50v, +/-10% |
| 5010-09361-00 | R43, R46, R47 | Resistor, 220Ω, 1/2w, 5% | 5046-09350-00 | C9 | Capacitor, 180P, 100v, +/-5% |
| 5010-09358-00 | R41, R42 | Resistor, 1K, 1/4w, 5% | 5520-09020-00 | X1 | Crystal, 3.58 MHz |
| 5010-08998-00 | R2, R3 | Resistor, 2.2K, 1/4w, 5% | 5521-10931-00 | CR1 | Oscillator, 8 MHz |
| 5010-08983-00 | R7-R9 | Resistor, 3.3K, 1/4w, 5% | 5551-09822-00 | L1 - L3 | Inductor, 4.7 μH, 3A |
| 5010-08991-00 | R1, R4, R5, R11, R25 - R26, R33, R36, R37, R49, R50 | Resistor, 4.7K, 1/4w, 5% | 5791-09437-00 | J4 | Connector, 20 pin, (Hdr), Rib. Cbl |
| | | | 5791-10862-04 | J1, J2, J5 | Connector, 4 pin (Hdr) |
| | | | 5791-10862-06 | J3 | Connector, 6 pin (Hdr) |
| | | | 16-8850-297 | | P.C.B. I.D. Label |

Notes: *20 capacitors (shown on diagram with "B" symbol) provide +5VDC filtering for ICs.
 All capacitors are ceramic, 50v, axial, unless otherwise noted.
 All resistors are 5%, 1/4w, Carbon Film, unless otherwise noted.

49 WAY JOYSTICK

| REV | DESCRIPTION OF CHANGE | DATE |
|-----|-----------------------|-------|
| 1 | PART RELEASE | 9856 |
| 2 | ORIGINAL ITEM 2 | 10199 |
| 3 | 20-8782-11 ITEM 1 | 14-83 |
| 4 | ITEM 2 03-7801 | |
| 5 | DESCRIPTIONIVE | |
| 6 | NUMBER | |
| 7 | PERFORMANCE CHANGE | 10337 |
| 8 | ADDED ITEM 4 | 10541 |
| 9 | 20-8782-11 MANIFOLD | 14-83 |
| 10 | ADDED NOTE 3 | |
| 11 | ADDED -15 | 20-11 |
| 12 | INFO TO CHART | 20-88 |
| 13 | ADDED ITEM 7D | 20-88 |
| 14 | CHART | 24-88 |



| DESCRIPTION (REV) | ASSEMBLY # | ITEM # |
|---------------------|------------|------------|
| 1/STK ASSY - RED | C-9477-4 | 20-9344-4 |
| 1/STK ASSY - ORANGE | C-9477-15 | 20-9344-15 |
| 1/STK ASSY - BLUE | C-9477-1 | 20-9344-1 |


- NOTES:**
- 1 ASSEMBLY MUST OPERATE FREELY WITHOUT ANY EVIDENCE OF BINDING OR INTERFERENCE.
 - 2 ELECTRICALLY TEST ASSEMBLY FOR PROPER OPERATION.
 - 3 LUBRICATE STEPPED SECTION OF ITEM 6 LIGHTLY WITH LUBRICANT *105 BEFORE FINAL ASSEMBLY.

| ITEM | QUANTITY | DESCRIPTION | UNIT | REV |
|------|----------|------------------------|------|-----|
| 1 | 1 | JOYSTICK W/NOSE | EA | 1 |
| 2 | 1 | RETAINING RING 3/8" | EA | 1 |
| 3 | 1 | ROLLER | EA | 1 |
| 4 | 1 | ROLLER | EA | 1 |
| 5 | 1 | ROLLER | EA | 1 |
| 6 | 1 | SENSING MECHANISM ASSY | EA | 1 |

| | | | | |
|-------------|--------------------|----------------------------------|-------|---|
| PROJ ENGR | DO NOT SCALE | REMOVE BURNS - BREAK SHARP EDGES | SCALE | 1 |
| DATE | WORK TO DIMENSIONS | | | |
| 28 8-30-82 | | | | |
| DESIGNED BY | DATE | FAST PROTECTING | | |
| W. J. JONES | 8-30-82 | | | |
| APPROVAL | DATE | FAST USAGE | | |
| W. J. JONES | 8-30-82 | | | |

| | |
|--------------------------------|----------------------|
| WILLIAMS ELECTRONICS, INC. | DESCRIPTION |
| 1000 S. Main Street, Suite 100 | JOYSTICK ASSY - BLUE |
| San Antonio, TX 78204 | Part No. C-9477-1 |


ANALOG DIGITAL 49W JOYSTICK ASSEMBLY P/N: C-9471



BILL OF MATERIAL

| ITEM NO. | PART NUMBER | PART DESIGNATION | DESCRIPTION | QTY REQD |
|----------|---------------|--------------------|--|----------|
| 1 | 5772-10068-00 | | BARE P.C. BOARD | 1 |
| 2 | 5430-10189-00 | OPTO 1 THRU OPTO 3 | OPTO INTER MODULE | 6 |
| 3 | 5310-09155-00 | IC 1 | I.C. 4018 CMOS GUARD 2-INP NAND GATE | 1 |
| 4 | 5019-09362-00 | SIP 1 | 10 PIN, 4.7K, SIP | 1 |
| 5 | 5010-09768-00 | R1 THRU R6 | RESISTOR, 180Ω, 1/4W | 6 |
| 6 | 5160-08936-00 | Q1 THRU Q6 | TRANSISTOR, 2N4401 NPN | 6 |
| 7 | 5070-08919-00 | D1 THRU D6 | DIODE, IN 4148 | 6 |
| 8 | 5791-10869-12 | 12 1 | 12H R/A SQ PIN .156 | 1 |
| 9 | 5010-09034-00 | R7 THRU R12 | RESISTOR, 10KΩ, 1/4W. | 6 |
| 10 | 5043-00994-00 | C 1 | CAP, AXIAL CERAMIC, .01MFD 50V, 80-207 | 1 |
| 11 | 16-8850-59 | | LABEL-PCB ASSY 2B | 1 |

PIGSKIN CPU BOARD





68K Mini Video Board C-13246-4004

| Description | Designation | Part Number | Description | Designation | Part Number |
|---------------------------|---|---------------|----------------------------------|---|----------------|
| 7406 IC | A17 | 5280-08974-00 | 390pF AX. CER. CAP. | C84,C78 | 5048-11064-00 |
| 74F00 IC | H1,E16 | 5283-10551-00 | 320pF AX. CER. CAP. | C48,C49,C50,C51,C52,C53, C54,C55,C56,C57,C58, C59,C60,C61,C65,C66, C74,C75 | 5048-12506-00 |
| 74F04 IC | B15,D15 | 5283-10552-00 | | | |
| 74F08 IC | CC17 | 5283-12488-00 | | | |
| 74F20 IC | D13 | 5283-12557-00 | .01uF AX. CER. CAP. | CP(1-131),C1,C2,C3,C77,C86, C87,C88 | 5043-08960-00 |
| 74F32 IC | CC13 | 5283-12488-00 | | | |
| 74F74 IC | CC2,D18 | 5283-10466-00 | 1uF AX. CER. CAP. | C85 | 5043-08966-00 |
| 74F86 IC | CC15,F4 | 5283-12486-00 | .47uF AX. CER. CAP. | C87 | 5048-12577-00 |
| 74F157 IC | H3 | 5283-12487-00 | FERRITE BEAD | FB1,FB2,FB3,FB4,FB5,FB6, FB7,FB8,FB9,FB10,FB11, FB12,FB13,FB14 | 5556-12513-00 |
| 74F174 IC | F13 | 5283-12484-00 | | | |
| 74HCS41 IC | A7,A9,A10,A16,A19 | 5311-12267-00 | | | |
| 74LS00 IC | D14 | 5281-09499-00 | 20 PIN HEADER (DUAL .100) | JP1 | 5791-08437-00 |
| 74LS02 IC | E13 | 5281-09247-00 | 8 PIN HEADER (.150) | JP2 | 5791-10862-00 |
| 74LS14 IC | B12 | 5281-09851-00 | 18 PIN HEADER (.100) | JP3 | 5791-12461-18 |
| 74LS20 IC | H10,CC14 | 5281-10014-00 | 12 PIN HEADER (.100) | JP4,JP5 | 5791-12461-12 |
| 74LS27 IC | D7 | 5281-09852-00 | 9 PIN HEADER (.100) | JP6 | 5791-12461-09 |
| 74LS32 IC | B16,CC16 | 5281-09500-00 | 4 PIN HEADER (.100) | JP8 | 5791-12461-04 |
| 74LS74 IC | H2,D10,B17,D17,B18 | 5281-09487-00 | RED LED | LED1 | 5671-09019-00 |
| 74LS86 IC | G3,E15 | 5281-09737-00 | JUMPER WIRE (00RES.) | JW1,JW2,JW3,JW6,JW9,JW10, JW13 | 5010-09534-00 |
| 74LS153 IC | G1,F3 | 5281-10016-00 | | | |
| 74LS157 IC | D8,B10,CC10,B11,B14, B13,D9,E4 | 5281-09738-00 | TIP110 TRANS. | Q1,Q2 | 5162-12508-00 |
| 74LS183 IC | D12,E12,D16 | 5281-10037-00 | MPSA70 TRANS. | Q3,Q4,Q5,Q6,Q7,Q8 | 5162-12507-00 |
| 74LS189 IC | F6,F9,F11,G13 | 5281-09855-00 | 2N4123 TRANS. | Q9 | 5160-12510-00 |
| 74LS173 IC | E14 | 5281-10040-00 | 2N3906 TRANS. | Q10 | 5190-10270-00 |
| 74LS174 IC | G2,G6,E17,E20 | 5281-09733-00 | PUSHBUTTON SWITCH | S1 | 5641-12551-00 |
| 74LS175 IC | E18 | 5281-10043-00 | 10 POS. DIP SWITCH | S2 | 5645-12512-00 |
| 74LS244 IC | E5,A11 | 5281-09867-00 | BATTERY HOLDER | BT1 | 5661-12315-00 |
| 74LS184 IC | G17,F18,G18,F19,G19, F20,G20,H20 | 5281-09743-00 | BARE PCB | PCB | 5770-12552-00 |
| 74LS245 IC | D4,E6 | 5281-09308-00 | 16 PIN IC SOCKET (.300) | CC18,D11 | 5700-09008-00 |
| 74LS258 IC | F16,F17 | 5281-09744-00 | 20 PIN IC SOCKET (.300) | CC11,D6,E10,E11,E18,F8,F14, F15 | 5700-09498-00 |
| 74LS273 IC | A1,F1,A2,F2,G4,G14 | 5281-09736-00 | 24 PIN IC SOCKET (.300) | D5,E9,F7,F12,G5,G9,G10,G11, G12 | 5700-12047-00 |
| 74LS283 IC | E8,F10 | 5281-09734-00 | | | |
| 74LS298 IC | H4,H5 | 5281-12514-00 | 28 PIN IC SOCKET (.300) | A14,B1,B7,B9,D3,E1,E2,E7 | 5700-10176-005 |
| 74LS374 IC | H6,G7,H7,G8,H8,H9, H11,H12 | 5281-09486-00 | 32 PIN IC SOCKET (.300) | A5,A8,B5,B8,H14,H15,H17,H18 | 700-12088-00 |
| 74LS377 IC | D1, D2,F5,G15,G16 | 5281-09741-00 | 64 PIN IC SOCKET (.300) | A3 | 5700-10453-00 |
| MAX805 IC | CC12 | 5434-12550-00 | 27512 ROM OHI | A5 | A-5343-4004-7 |
| 16MHz CRYSTAL OSC | CC1 | 5521-12501-00 | 27512 ROM 1H1 | A6 | A-5343-4004-6 |
| 20MHz CRYSTAL OSC | D19 | 5521-10743-00 | 27512 ROM 0L0 | B5 | A-5343-4004-5 |
| 10 RES., 5% 1/4 WATT | R63,R64,R72,R73,R76,R77 | 5010-09039-00 | 27512 ROM 1L0 | B6 | A-5343-4004-4 |
| 22 RES., 5% 1/4 WATT | R92 | 5010-09434-00 | 27512 ROM BG1 | E1 | A-5343-4004-9 |
| 47 RES., 5% 1/4 WATT | R86,R87,R88,R90 | 5010-10170-00 | 27512 ROM BG0 | E2 | A-5343-4004-8 |
| 68 RES., 5% 1/4 WATT | R85,R89,R93 | 5010-12480-00 | 27010 ROM FG3 | H14 | A-5343-4004-10 |
| 100 RES., 5% 1/4 WATT | R17,R18,R19,R20,R21,R22, R23,R24,R25,R26,R27, R28,R29,R30,R110 | 5010-09036-00 | 27010 ROM FG0 | H15 | A-5343-4004-11 |
| 330 RES., 5% 1/4 WATT | R118 | 5010-09001-00 | 27010 ROM FG1 | H17 | A-5343-4004-12 |
| 470 RES., 5% 1/4 WATT | R65,R74, R75 | 5010-09416-00 | 27010 ROM FG2 | H18 | A-5343-4004-13 |
| 510 RES., 5% 1/4 WATT | R68,R71,R80 | 5010-12483-00 | 2Kx8 RAM, 120nS | D3,E7 | 5340-12506-00 |
| 560 RES., 5% 1/4 WATT | R62,R81,R82 | 5010-08992-00 | 2018-45, 2Kx8 RAM, 45nS | G9,G10,G11,F12,G12 | 5340-12497-00 |
| 1K RES., 5% 1/4 WATT | R67,R70,R79,R113,R115 | 5010-09358-00 | 100nS 8Kx8 RAM, (ultra low pwr.) | B7,B9 | 5340-12558-00 |
| 2K RES., 5% 1/4 WATT | R66,R69,R78 | 5010-09999-00 | 93419, 64x9 RAM | A14 | 5340-12498-00 |
| 2.7K RES., 5% 1/4 WATT | R31,R32,R33,R34,R35, R36,R37 | 5010-08997-00 | MC8040 IC | B1 | 5431-12499-00 |
| 4.7K RES., 5% 1/4 WATT | R83,R84,R91,R98,R99,R100, R101,R102,R103,R104, R105,R108,R109,R111, R112,R114,R116,R117, R119,R120 | 5010-08991-00 | 68000 IC | A3 | 5400-12498-00 |
| 10K RES., 5% 1/4 WATT | R1,R2,R3,R4,R5,R6,R7,R8, R9,R10,R11,R12,R13,R14, R15,R16,R38,R39,R40,R41, R42,R43,R44,R45,R46,R47, R48,R49,R50,R51,R52,R53, R54,R55,R56,R57,R58,R59, R60,R61 | 5010-09034-00 | PACOUT IC, PLD | F15 | A-5346-4004-1 |
| 1K SIP RES., 10 PIN | RM6,RM7,RM8,RM9 | 5019-09669-00 | PACNS IC, PLD | F14 | A-5346-4004-2 |
| 100K SIP RES., 10 PIN | RM1,RM2,RM3,RM4,RM5 | 5019-12509-00 | ROMCTRL IC, PLD | E19 | A-5346-4004-3 |
| 4.7K SIP RES., 10 PIN | RM10 | 5019-09362-00 | VERTTIME IC, PLD | F7 | A-5346-4004-4 |
| 10uF RD. ELEC. CAP., 10V | C82,C83 | 5041-09243-00 | HORIZTIME IC, PLD | E9 | A-5346-4004-5 |
| 470uF RD. ELEC. CAP., 10V | C4,C5,C6,C7,C89 | 5040-09778-00 | MISCV IC, PLD | F8 | A-5346-4004-6 |
| 47pF AX. CER. CAP. | C68,C69,C70,C71,C72,C73 | 5043-09844-00 | MISCHV IC, PLD | E11 | A-5346-4004-7 |
| 100pF AX. CER. CAP. | C8,C9,C10,C11,C12,C13,C14, C15,C16,C17,C18,C19,C20, C21,C22,C23,C24,C25,C26, C27,C28,C29,C30,C31,C32, C33,C34,C35,C36,C37,C38, C39,C40,C41,C42,C43,C44, C45,C46,C47 | 5048-11029-00 | COLARB IC, PLD | G5 | A-5346-4004-8 |
| | | | DECODE0 IC, PLD | D5 | A-5346-4004-9 |
| | | | DECODE1 IC, PLD | D8 | A-5346-4004-10 |
| | | | DECODE2 IC, PLD | CC11 | A-5346-4004-11 |
| | | | HENABLE IC, PLD | E10 | A-5346-4004-12 |
| | | | 74LS368 IC | CC18 | 5281-09748-00 |
| | | | 74LS157 IC | D11 | 5281-09738-00 |
| | | | 3.6V BR2325 BATTERY | BT1 | 5880-11056-00 |
| | | | 1/4 SPACER | | 03-8338-1 |
| | | | SUB-ASSEMBLY | | C-13247-1 |
| | | | LABEL | | 16-8800-29B |


POWER SUPPLY SWITCHER ASSEMBLY

p/n C-13253

| Part Number | Description |
|-------------|--------------------|
| 20-9633 | Power Supply, 85W |
| 01-9254 | Shield |
| 16-8587-701 | High Voltage Label |



LAMP DRIVER ASSEMBLY



P/N: C-13765

| Part Number | Part Designation | Description |
|---------------|---|--------------------------|
| 5311-12669-00 | U3 | IC, 74HCT14 |
| 5311-12668-00 | U1,U2 | IC, 74HCT273 |
| 5010-09416-00 | R24,R25,R26,R27,R28,R29, R30,R31,R32,R33,R34, R35,R36,R37,R38,R39 | 470, 5%, 1/4W, Resistor |
| 5010-09034-00 | R2,R4,R6,R8,R10,R12,R14, R16,R18,R20,R22 | 10K, 5%, 1/4W, Resistor |
| 5010-09162-00 | R1,R3,R5,R7,R9,R11,R13, R15,R17,R19,R21,R23 | 100K, 5%, 1/4W, Resistor |
| 5040-08986-00 | C14 | 100uF, 10V, Capacitor |
| 5040-12670-00 | C15 | 2200uF, 16V, Capacitor |
| 5048-11029-00 | C1,C2,C3,C4,C5,C6,C7,C8, C9,C10,C11 | 100pF, Capacitor |
| 5043-09845-00 | C12,C13 | .001uF Capacitor |
| 5043-08980-00 | B1,B2,B3 | .01uF Capacitor |
| 5551-09822-00 | L1 | 4.7 uH, Inductor |
| 5731-09128-00 | F1,F2 | FUSE 2.5A SB |
| 5791-10862-07 | J1 | 7 PIN HEADER (.156) |
| 5791-10862-05 | J2,J8 | 5 PIN HEADER (.156) |
| 5791-12461-18 | J7 | 18 PIN HEADER (.100) |
| 5791-12461-10 | J4,J5 | 10 PIN HEADER (.100) |
| 5791-12461-06 | J6 | 6 PIN HEADER (.100) |
| 5791-12461-05 | J3 | 5 PIN HEADER (.100) |
| 5070-09045-00 | D1,D3 | MR501, DIODE |
| 5162-12508-00 | Q1,Q2,Q3,Q4,Q5,Q6,Q7,Q8, Q9,Q10,Q11,Q12,Q13,Q14, Q15,Q16 | TIP110, TRANSISTOR |
| 5010-09534-00 | D2 | WIRE JUMPER |
| 5733-12060-01 | F1,F2 | FUSE HOLDER |
| 5763-12665-00 | | PCB |
| 03-8338-1 | | SPACER, 1/4" |
| 16-8850-308 | | LABEL, PCB ID |


PIGSKIN

Diagrams & Schematics

S
E
C
T
I
O
N

T
H
R
E
E


AUDIO SCHEMATIC P/N: 16-8999




WILLIAMS ELECTRONIC GAMES, INC.
 554
 145 W. JACKSON AVE. CHICAGO, ILL. 60604
 AUDIO SYSTEM SCHEMATIC
 16-8999

E
 REVISIONS
 16-8999


ANALOG DIGITAL 49W JOYSTICK SCHEMATIC P/N: 16-8862




PCB Schematic Sheet 1 of 12




PCB Schematic Sheet 3 of 12




PCB Schematic
Sheet 5 of 12




PCB Schematic
Sheet 8 of 12




PCB Schematic Sheet 9 of 12




PCB Schematic
Sheet 10 of 12



PCB Schematic
Sheet 11 of 12



PCB Schematic
Sheet 12 of 12




PIGSKIN
Jamma Chart


| Function | Wire Color | Pin | Pin | Wire Color | Function |
|--------------|------------|-----|-----|------------|--------------|
| GROUND | BLK | 1 | A | BLK | GROUND |
| GROUND | GRN-BRN | 2 | B | BLK | GROUND |
| +5 VOLTS DC | GRY | 3 | C | GRY | +5 VOLTS DC |
| +5 VOLTS DC | GRY | 4 | D | GRY | +5 VOLTS DC |
| - 5 VOLTS DC | GRY-GRN | 5 | E | GRY-GRN | - 5 VOLTS DC |
| +12 VOLTS DC | GRY-YEL | 6 | F | GRY-YEL | +12 VOLTS DC |
| | KEY | 7 | H | KEY | |
| COUNTER 1 | WHT-ORG | 8 | J | WHT-GRN | COUNTER 2 |
| | NC | 9 | K | NC | |
| SPEAKER (+) | RED-VIO | 10 | L | GRN-VIO | SPEAKER (-) |
| | NC | 11 | M | NC | |
| VIDEO RED | RED | 12 | N | GRN | VIDEO GRN |
| VIDEO BLU | BRN | 13 | P | WHT | VIDEO SYNC |
| VIDEO GND | SHIELD | 14 | R | WHT-RED | SERVICE |
| TEST | GRN | 15 | S | WHT-VIO | TILT |
| COIN 1 | WHT-BLU | 16 | T | YEL-WHT | COIN 2 |
| START 1 | YEL-GRN | 17 | U | YEL-BLU | START 2 |
| NC | ORG-BLK | 18 | V | NC | |
| NC | ORG-BRN | 19 | W | NC | |
| NC | ORG-RED | 20 | X | NC | |
| NC | ORG | 21 | Y | NC | |
| 1 PUNCH | ORG-YEL | 22 | Z | YEL-VIO | 2 PUNCH |
| 1 PASS | ORG-GRN | 23 | a | YEL-GRY | 2 PASS |
| 1 ATT. ADJ. | ORG-BLU | 24 | b | VIO-BLK | 2 ATT. ADJ. |
| NC | ORG-VIO | 25 | c | VIO-BRN | NC |
| NC | ORG-GRY | 26 | d | VIO-RED | NC |
| | NC | 27 | e | NC | |
| GROUND | BLK | 28 | f | BLK | GROUND |

PIGSKIN 4004-U CONTROL PANEL WIRING DIAGRAM


Cable p/n: H-13790



PIGSKIN LAMP DRIVER BOARD




PIGSKIN POWER WIRING DIAGRAM





Schematic diagram shows Jumper for 115V Jumpers.
See chart for other voltage Jumper connections.

| TRANSFORMER JUMPER CHART | | | |
|--------------------------|---------------|---------------|---------------|
| 103.5VAC | 206VAC | 218VAC | 230VAC |
| | | | |
| Fuse 3A SLO | Fuse 2A SLO | Fuse 2A SLO | Fuse 2A SLO |
| Varistor 130V | 275V | 275V | 275V |
| 130V Varistor | 275V Varistor | 5017-09044-00 | 5017-09063-00 |
| 2A SB Fuse | 3A SB Fuse | 5017-08665-00 | 5017-10056-00 |



PIGSKIN INTERBOARD WIRING



From Player 1 Joystick

From Player 2 Joystick

To Lamp Board

To Monitor

| | |
|----|------------------|
| 1 | NC |
| 2 | 1/U/D DIR |
| 3 | RED-BLU |
| 4 | RED-GRN |
| 5 | RED-YEL |
| 6 | KEY |
| 7 | NC |
| 8 | 1/L/R DIR |
| 9 | RED-ORG |
| 10 | 1/L/R 3 |
| 11 | RED-BRN |
| 12 | 1/L/R 1 |
| 13 | RED-BLK |
| 14 | 2/L/R 1 |
| 15 | BLU-BLK |
| 16 | 2/L/R 2 |
| 17 | BLU-BRN |
| 18 | 2/L/R 3 |
| 19 | BLU-RED |
| 20 | 2/L/R DIR |
| 21 | BLU-ORG |
| 22 | KEY |
| 23 | NC |
| 24 | 2/U/D 1 |
| 25 | BLU-YEL |
| 26 | 2/U/D 2 |
| 27 | BLU-GRN |
| 28 | 2/U/D 3 |
| 29 | BLU |
| 30 | 2/U/D DIR |
| 31 | BLU-VIO |
| 32 | NC |
| 33 | Lamp Stroke 1 |
| 34 | BLK-BRN |
| 35 | Lamp Stroke 0 |
| 36 | BLK-RED |
| 37 | Lamp Horest |
| 38 | BLK-ORG |
| 39 | NC |
| 40 | KEY |
| 41 | NC |
| 42 | Lamp Data 7 |
| 43 | BLK-YEL |
| 44 | Lamp Data 6 |
| 45 | BLK-GRN |
| 46 | Lamp Data 5 |
| 47 | BLK-BLU |
| 48 | Lamp Data 4 |
| 49 | BLK-VIO |
| 50 | Lamp Data 3 |
| 51 | BLK-GRY |
| 52 | Lamp Data 2 |
| 53 | BLK-WHT |
| 54 | Lamp Data 1 |
| 55 | VIO-ORG |
| 56 | Lamp Data 0 |
| 57 | VIO-YEL |
| 58 | NC |
| 59 | RED VIDEO-RED |
| 60 | NC |
| 61 | GRY VIDEO-GRN |
| 62 | NC |
| 63 | BRN VIDEO-BLU |
| 64 | SHIELD VIDEO-GND |
| 65 | KEY |
| 66 | WHIT VERT. SYNC |
| 67 | BLK HORIZ. SYNC |

JAMMA EDGE CONNECTOR
(See JAMMA Chart Page 3-15)

PIGSKIN Inserted Jumpers

AUDIO BOARD
P/N D-11581-4004

W2
W9
W11

PIGSKIN CPU BOARD
P/N C-13246-4004

W1
W2
W3
W6
W9
W10
W13

WARNINGS & NOTICES

Warning

USE OF NON-MIDWAY PARTS OR CIRCUIT MODIFICATIONS MAY CAUSE SERIOUS INJURY OR EQUIPMENT DAMAGE! USE ONLY MIDWAY AUTHORIZED PARTS.

- * For safety and reliability, substitute parts and modifications are not recommended.
- * Substitute parts or modifications may void FCC type acceptance.
- * This game is protected by federal copyright, trademark and patent laws.

Unauthorized modifications may be illegal under Federal law. This also applies to Midway logos, designs, publications and assemblies. Moreover, facsimiles of Midway equipment (or any feature thereof) may be illegal under federal law, regardless of whether or not such facsimiles are manufactured with Midway components.

Warning

This equipment generates, uses and can emit radio frequency energy and, if not installed properly and used according to the directions in this manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of part 15 of FCC rules which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference to radio communications, in which the user, at his or her own expense, will be required to take whatever measures may be needed to correct the interference.

Warning

Prevent shock hazard and assure proper game operation. Only plug this game into a properly grounded outlet. Do not use a cheater plug to defeat the power cord's grounding pin. Do not cut off the ground pin.

Notice

No part of this publication may be reproduced by any mechanical, photographic, or electronic process, or in the form of a phonographic recording, nor may be transmitted, or otherwise copied for public or private use, without permission from the publisher.

**MIDWAY MANUFACTURING COMPANY
3401 N. CALIFORNIA AVE.
CHICAGO, ILLINOIS 60618**